



### ALIGNMENT PROCEDURE

| Step | Generator Connection | Generator Frequency | Dial pointer           | Adjustment | Indication |
|------|----------------------|---------------------|------------------------|------------|------------|
| 1    | Test Loop            | 455 KC              | Tuning Gang fully open | IT 1, 2, 3 | Max Output |
| 2    | Same                 | 520 KC              | Tuning Gang fully open | L2         | Same       |
| 3    | Same                 | 1650 KC             | Tuning Gang fully open | C1B        | Same       |
| 4    | Repeat Steps 2 and 3 |                     |                        |            |            |
| 5    | Same                 | 600 KC              | 600 KC                 | L1         | Same       |
| 6    | Same                 | 1400 KC             | 1400 KC                | C1C        | Same       |
| 7    | Repeat Steps 5 and 6 |                     |                        |            |            |

